

## JV85 Troubleshooting

Trouble	Possible Causes	Solutions
<b>Motor Does not work</b>	<ul style="list-style-type: none"><li>▪ Battery has no power</li></ul>	<ul style="list-style-type: none"><li>▪ Charge the vacuum cleaner</li></ul>
	<ul style="list-style-type: none"><li>▪ Metal tube, floorhead, battery pack and vacuum cleaner is not assembled correctly.</li></ul>	<ul style="list-style-type: none"><li>▪ Check the accessories are assembled correctly to the vacuum cleaner.</li></ul>
<b>Suction Drops</b>	<ul style="list-style-type: none"><li>▪ Dust cup full</li></ul>	<ul style="list-style-type: none"><li>▪ Clean dust cup</li></ul>
	<ul style="list-style-type: none"><li>▪ Filter blocked</li></ul>	<ul style="list-style-type: none"><li>▪ Clean or replace filter</li></ul>
	<ul style="list-style-type: none"><li>▪ Floorhead air path blocked</li></ul>	<ul style="list-style-type: none"><li>▪ Clean floorhead air path</li></ul>
<b>Short working time after charging</b>	<ul style="list-style-type: none"><li>▪ Machine not fully charged</li></ul>	<ul style="list-style-type: none"><li>▪ Follow instruction manual to fully charge the battery.</li></ul>
	<ul style="list-style-type: none"><li>▪ Battery old aging</li></ul>	<ul style="list-style-type: none"><li>▪ New batteries can be bought from local distributor</li></ul>

**JIMMY**